


HYDRAULIC ACCUMULATORS SPARE PARTS TYPE EHV/EHVF

Type EHV 330/350 bar Spare Code


Designazione Designation	Kit ricambio (1) Repair kit	Sacca (2) Spare bladder	Guarnizioni (3) Seal kit	Bussola (4) Anti extrusion ring	Valvola olio (5) Liquid valve
EHV 0,2 - 350 /..	190010 - 00220	111277 - 00220	107496 - 00033	100039 - 00220	108951 - 00220
EHV 0,5 - 350 /..	190011 - 00225	111280 - 00225	107497 - 00033	100076 - 00220	108642 - 00220
EHV 1 - 350 /..	190364 - 00225	110462 - 00225	108080 - 00033	100076 - 00220	108642 - 00220
EHV 1,6 - 350 /..	190096 - 00225	105323 - 00225	108081 - 00033	100076 - 00220	108642 - 00220
EHV 2,5 - 350 /..	190365 - 00225	110463 - 00225	108082 - 00033	100014 - 00220	108608 - 00220
EHV 4 - 350 /..	190366 - 00225	110465 - 00225	108083 - 00033	102119 - 00220	108570 - 00220
EHV 5 - 350 /..	190367 - 00225	110464 - 00225	108082 - 00033	100014 - 00220	108608 - 00220
EHV 6 - 350 /..	190368 - 00225	110467 - 00225	108083 - 00033	102119 - 00220	108570 - 00220
EHV 10 - 350 /.. - L	190369 - 00225	110468 - 00225	108083 - 00033	102119 - 00220	108570 - 00220
EHV 10 - 330 /.. - K	190358 - 00225	110469 - 00225	108084 - 00033	100100 - 00220	110298 - 00220
EHV 12 - 330 /..	190359 - 00225	110470 - 00225	108084 - 00033	100100 - 00220	110298 - 00220
EHV 20 - 330 /..	190360 - 00225	110471 - 00225	108084 - 00033	100100 - 00220	110298 - 00220
EHV 24 - 330 /..	190363 - 00225	110472 - 00225	108084 - 00033	100100 - 00220	110298 - 00220
EHV 32 - 330 /..	190361 - 00225	110473 - 00225	108084 - 00033	100100 - 00220	110298 - 00220
EHV 50 - 330 /.. Ød = 22	190542 - 00225	110475 - 00225	108084 - 00033	100100 - 00220	110298 - 00220
EHV 50 - 330 /.. Ød = 50	190362 - 00225	110624 - 00225	108084 - 00033	100100 - 00220	110298 - 00220



HYDRAULIC ACCUMULATORS SPARE PARTS TYPE EHV/EHVF


Type EHVF 330/350 bar Spare Code

Designazione Designation	Kit ricambio (1) Repair kit	Sacca (2) Spare bladder	Guarnizioni (3) Seal kit	Bussola (4) Anti extrusion ring	Valvola olio (5) Liquid valve
EHVF 2,5 - 350/90	190010 - 00220	111277 - 00220	107496 - 00033	100039 - 00220	108619 - 00220
EHVF 4 - 350/90	190011 - 00225	111280 - 00225	107497 - 00033	100076 - 00220	108585 - 00220
EHVF 5 - 350/90	190364 - 00225	110462 - 00225	108080 - 00033	100076 - 00220	108619 - 00220
EHVF 6 - 350/90	190096 - 00225	105323 - 00225	108081 - 00033	100076 - 00220	108585 - 00220
EHVF 10 - 350/90	190365 - 00225	110463 - 00225	108082 - 00033	100014 - 00220	108585 - 00220
EHVF 10 - 330/90	190366 - 00225	110465 - 00225	108083 - 00033	102119 - 00220	108543 - 00220
EHVF 12 - 330/90	190367 - 00225	110464 - 00225	108082 - 00033	100014 - 00220	108543 - 00220
EHVF 20 - 330/90	190368 - 00225	110467 - 00225	108083 - 00033	102119 - 00220	108543 - 00220
EHVF 24,5 - 330/90	190369 - 00225	110468 - 00225	108083 - 00033	102119 - 00220	108543 - 00220
EHVF 32 - 330/90	190358 - 00225	110469 - 00225	108084 - 00033	100100 - 00220	108543 - 00220
EHVF 42 - 330/90	190359 - 00225	110470 - 00225	108084 - 00033	100100 - 00220	108543 - 00220
EHVF 50 - 330/90	190360 - 00225	110471 - 00225	108084 - 00033	100100 - 00220	108543 - 00220
EHVF 57 - 330/90	190363 - 00225	110472 - 00225	108084 - 00033	100100 - 00220	108543 - 00220



HYDRAULIC ACCUMULATORS SPARE PARTS TYPE EHV/EHVF

Type EHV/EHVF Tightening torques



Taglia accumulatore Accu size	Anello di bloccaggio Locking ring	Dado di bloccaggio Lock nut	Cuore valvola gas Gas valve core	Corpo valvola gas Gas valve body
Fino a 1 Lt	120 Nm	80 - 110 Nm	0,25 - 0,29 Nm	15 Nm
2,5-10 Lt: lungo	210 Nm	80 - 110 Nm	0,25 - 0,29 Nm	15 Nm
10-50 Litri	240 Nm	80 - 110 Nm	0,25 - 0,29 Nm	15 Nm